






B50FL B50DL B50WL B75RFL B75RDL

Instruction of installation:


- -Read the instructions carefully before installation and commissioning.
- —The safety of the device can only be guaranteed on condition that to be respected the following instructions, both stages of installation and use therefore it is highly recommended to keep them.
- —When installing, always observe the national installation and accident prevention regulations.
- —Installation and commissioning may only be carried out by authorized specialists.
- —The device cannot be in any case modified or forced, any modification might jeopardize the safety system making it dangerous. LiteMatrix declines any responsibility on modified products



FOR INDOOR USE ONLY!









ATTENTION: For ceiling recessed mounting. Luminaire not suitable for being covered with heavy staffs or thermally insulating materials.








Table 1-Specs

	Aperture	Height	Cutout	Thickness	Depth
	D/mm	H/mm	W/mm	S/mm	mm
B50FT	Ф50	94	Φ54	5-25	>130
B50DT	Ф50	98-108	Ф54	5-25	>130
B50WT	Ф50	84	Ф54	5-25	>130
B75RFT	Ф75	116	Ф80	5-25	>140
B75RDT	Ф75	121	Ф80	5-25	>140

- -Lateral air space under EN 60598: The lateral distance between the surface of the luminaire and any parts of the building must be no less than 50mm.
- -Please be sure enough space has been left for mounting.
- -Recommended mounting and using environment: Ta=25°C.

LITEMATRIX(HK) CO LIMITED

Phone: +852 3050 1787

Fax:

LiteMatrix reserves the right to make technical and design changes without prior notice.

www.litematrixlighting.com E-

Flat A 8/F No.227 Nathan Road Yau Ma Tei Kowloon Hongkong

E-mail: sales@litematrix.net

+852 3050 6957

2017.10



Black Recessed Downlight



Luminaire mounting


1. During the installation, make sure the power supply is disconnected. Put on gloves and operate in dry environment

2. Ceiling cutout

3. Casing mounting

4. Mounting surface treatment

5. Connect to power supply







into the ceiling

 Following these steps below to install or change the reflector


6. Put power supply and luminaire















ATTENTION: Make sure the mounting direction of reflector is correct as below for B50D models.



Cleaning

Always clean carefully using a soft cloth and a commercially available, phneutral, alcohol-free, non-abrasive cleaning agent.

Disposal




In accordance with EU Directive WEEE (Waste Electrical and Electronic Equipment), luminaires must not be disposed of with other household waste. At the end of their life, luminaires must be taken to the appropriate local facility available for the disposal or recycling of electronic products.


- h - l -

Adjustment for B50DT

Remove the reflector, using mechanical wrench to adjust.










Adjustment for B75RDT

Remove the reflector, using fingers to adjust.



LITEMATRIX(HK) CO LIMITED

Phone: +852 3050 1787

Fax: +852 3050 6957

F-mail

sales@litematrix.net

2017.10 2 / 2